

Bromine Spa Start Up Kit Instructions

1) Testing your spa water

After filling your spa use the Aquachek™ test strips to measure your pH level.

If your pH is low, add Spa pH Plus: follow the dosage instructions on the label for Spa pH Plus for your spa gallons.

If your pH is high add Spa pH Minus: follow the dosage instructions on the label for Spa pH Minus for your spa gallons.

2) Treat for stain prevention

Add Spa Metal Out: follow the dosage instructions on the label for Spa Metal Out for your spa gallons.

3) Add Bromine

Fill your bromine dispenser with the bromine tablets and set it in the water: follow the dosage instructions on the label for Brominating Tablets for your spa gallons.

4) Shock the Spa

Add Spa Care Spa Shock Oxidizer: follow the dosage instructions on the label for Spa Care Spa Shock Oxidizer for your spa gallons.

- 5) Maintaining your spa:** Test your spa weekly and adjust your pH as needed. Shock weekly to reactivate your Bromine and after heavy use. Add more bromine tablets as they erode away. Clean your Cartridge filter monthly, replace it annually.

Enjoy your spa!