



FLOWSKIM VENTED BASKET HANDLE

CMP# 25573-300

PATENT PENDING

The FlowSkim Basket Handle provides a bypass for water flow when the skimmer basket is full of debris. FlowSkim protects the pump from operating dry which can cause damage. The FlowSkim design allows for easier removal from the skimmer, and makes emptying the basket cleaner, faster, and easier.



Tools Needed: Phillips Head Screwdriver

1. Locate the two upper mounting holes on the skimmer basket just under the upper lip. See Fig. 1. Note: If basket does not have upper mounting holes they can be manually added by drill. Use the FlowSkim Handle as a template for location.

2. Install the two upper mounting screws through the basket and into the upper mounting holes in the FlowSkim Handle. See Fig. 2.

3. Find the existing strainer holes in the basket that are nearest to the lower mounting holes in the FlowSkim Handle. Install the two lower mounting screws through the basket and into the lower mounting holes in the FlowSkim Handle. See Fig. 3.

NOTE: Please see pump manufacturer's technical information regarding necessary water flow required for minimal operation. This product is not intended to solve low water flow issues with the pump.




FIG. 1



FIG. 2




FIG. 3