

INCLUDES: Fountain, remote control and AC adapter

WARNING

SEIZURES - People with photosensitive epilepsy can have seizures triggered by flickering or flashing lights such as strobe or disco lights.

Do not operate the product in water while the unit is plugged in.
Serious and/or fatal injury may result.

To prevent damage to the pump, do not run the fountain out of water.

KEEP OUT OF REACH OF CHILDREN. THIS IS NOT INTENDED AS A TOY.

NOTE

- The product projects light show approximately 10-15 feet in diameter.
- Fountain has preset programming running at various heights.
- Light show intensity will vary according to color, size and depth of your pool.

GETTING STARTED

IMPORTANT: Product must be charged before use.


1. Plug the AC adapter into an electrical wall outlet.
2. Remove the charging port plug located on top of the fountain.
3. Plug the AC adapter connector into charging port.
4. When the product is fully charged, 6 to 8 hours, the charging indicator (red light) will turn blue.
5. Unplug the charger from the charging port.
6. Replace the charging port plug, pressing it firmly in place so water does not seep into the port.
7. Remote control comes with a button cell battery (lithium CR2032, 3 volts) installed.
Pull clear plastic tab at side of remote to enable battery connection.

OPERATION

You can use the remote control or the button on the product to operate the fountain and light shows.

The remote control must be pointed directly at the product for it to function.

Press the  button for the fountain and the underwater light shows.

Press the  button for the upper and underwater light shows only (no fountain).

Press  followed by  button for the fountain only (no light shows).

Pressing the same button twice turns off that feature.

WARNING: Use the supplied battery charge adapter; DO NOT substitute with any other charger. Never turn on the product while is charging.

IMPORTANT:

- Remove from pool when not in use or while cleaning so unit is not damaged by skimmers or other devices.
- Do not submerge unit in water as this could damage the electronic components.
- This product should be operated in at least 12 inches of water to get the maximum water height. It is recommended to clean out the filter screen at bottom of unit periodically to ensure proper water flow.



CLEANING & MAINTENANCE

Wipe dry with a soft cloth after use.

STORAGE

When the product is out of water, it should be stored in a cool, dry place. Do not leave the product in direct sunlight as this could damage the batteries.

IMPORTANT: The batteries in AquaJet are permanently sealed in the product and cannot be removed or replaced. Attempting to remove and/or replace the batteries will void the warranty. The battery in the remote control is replaceable.



TROUBLESHOOTING

Problem	Possibilities/Solutions
Fountain will not function	Check to make sure it is charged
	Try pushing another button, or using the remote
	Make sure the fountain body is not cracked, causing a leak
	Make sure the fountain was not run or placed in the pool with the Charge Port Cap loose or off, causing a leak
Light show will not function	Check to make sure it is charged
	Try pushing another button, or using the remote
The fountain spray height seems low, or uneven	Check for blockages on the intake screen at the bottom of the fountain body, and clear them
	Check for visible blockages in the outlet spray holes on top of the fountain. If there are blockages, these may be cleared with a thin wire, a pin, or a needle. Be sure not to force or enlarge the spray holes, as this will permanently alter the spray pattern
	Check fountain charge
The light show isn't bright on my pool floor	Check fountain charge
	If your pool floor is colored vinyl, "pebble tech", or other dark or colored material, some colors may not show up as well
The fountain seems to shut off too soon	Check fountain charge
	Check for blockage on the intake screen at the bottom of the fountain body, and clear them – this can cause the pump motor to work too hard
	Discharge the fountain completely by running it until it stops, then charge it again for a full eight hours or until the charge indicator light turns Blue
The remote control doesn't seem to work	Check to make sure that the plastic tab along the side of the remote has been pulled out, activating the remote
	Activate your mobile phone camera, and point the LED at the end of the remote into the camera lens. Press the remote buttons, and look at the mobile phone display. You should see a violet light flashing (this works for any IR remote control). If there is no light visible, replace the battery by removing the remote's bottom cover (one small Phillips head screw). Be sure to replace the cover and the screw for safety.

NOTE

- Do not mix old and new batteries.
- Do not dispose batteries into fire. Batteries may explode or leak.
- Do not mix alkaline standard (carbon-zinc), or rechargeable (nickel-cadium) batteries.
- Replace batteries ensuring the correct battery type, and as a simultaneous act.
- Remove batteries if product is to be left unused for a long time.
- Clean the battery contacts and also those of the devices prior to battery installation.
- The supply terminal is not to be short circuited (+) (-).
- Non-rechargeable batteries are not to be recharged.
- Batteries are to be inserted with the correct polarity.
- Remove exhausted batteries promptly and dispose of properly.

Check your local regulations for proper disposal instructions of batteries.

CAUTION: Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT.

This Class B digital apparatus complies with Canadian ICES-003.

LIMITED WARRANTY STATEMENT

General Terms

This Limited Warranty applies to the product enclosed ("the Product") distributed by Great American Duck Races, Inc., an Arizona corporation, doing business as Great American Marketing and Events ("GAME"), sold with this Limited Warranty Statement. This Limited Warranty is applicable in all countries. • GAME warrants that the Product you have purchased from GAME is free from defects in materials or workmanship under normal use during the warranty period. The warranty period starts on the date of purchase and continues for ninety (90) days. Your dated sales or delivery receipt, showing the date of purchase of the Product, is your proof of the purchase date. • During the warranty period, GAME will repair or replace any defective parts with new parts, or, at GAME's discretion, used parts that meet or exceed performance specifications for new parts. All parts removed under this warranty become the property of GAME. The replacement part takes on the warranty status of the removed part or product. • This Limited Warranty does not apply to expendable parts. This Limited Warranty does not extend to any product from which the serial number has been removed or that has been damaged or rendered defective (a) as a result of accident, misuse, abuse or other external causes; (b) by operation outside the usage parameters stated in the Instruction Sheet that shipped with the Product; (c) by the use of parts not manufactured or sold by GAME; or (d) by modification or service by anyone other than GAME.

Limitation of Liability

GAME is not liable for any damages caused by the Product or the failure of the Product to perform, including any direct or indirect damages for personal injury, lost profits, lost savings, incidental damages, consequential damages, or any other pecuniary loss arising out of the use or inability to use the Product. GAME is not liable for any claim made by a third party or made by you for a third party. • This limitation applies whether damages are sought, or a claim made, under this Limited Warranty or as a tort claim (including negligence and strict product liability), a contract claim, or any other claim. This limitation cannot be waived or amended by any person. This limitation of liability will be effective even if you have advised GAME or an authorized representative of GAME of the possibility of any such damages.

EXCEPT AS EXPRESSLY SET FORTH IN THIS LIMITED WARRANTY, GAME MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. GAME EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS WORLDWIDE LIMITED WARRANTY STATEMENT.

To obtain warranty service, please call, write, or email us directly at the address shown below.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

WARNING: GAME™ has in the past, and will in the future, take any and all legal steps necessary in order to protect our proprietary trademarks, patents, trade dress, and copyrights. This applies to, but is not limited to, products, product design, graphics, packaging and literature. We will prosecute to the fullest extent of the law any persons or entities who infringe upon these rights.



Great American Merchandise & Events™
16444 N. 91st Street
Scottsdale, AZ 85260-1567 USA

tel: 888.382.5988
fax: 602.957.7665

email: products@game-group.com
www.game-group.com

Designed in the USA. Made in China.
U.S. Patents 7,413,319 & 7,717,582