



SkimDoctorTM
Turbocharge Your Pool Skimmer

QUICK INSTALLATION GUIDE

For In Ground SkimDoctor 2.0

Step 1

If needed! The blue ring washer is assembled like a puzzle piece and is used for large baskets.



Step 2

Place silver primary ring on top of your skimmer basket "or" blue ring.



Step 3

Insert the two brass rods through bottom of your skimmer basket.



Step 4

Screw on blue sleeves through top slots of the SkimDoctor to connect ring(s) permanently to your skimmer basket.



Step 5

Screw SkimDoctor adjustable tube into silver ring. Add security caps to rods.



Step 6

Unscrew SkimDoctor tube for easy emptying of your basket.



For all questions and operating instructions scan code or visit the FAQ section at: SkimDoctor.com

*Enjoy your
clean pool!*

Vac Attachment
Sold separately:

Remove SkimDoctor
Tube and screw in
SkimDoctor
Vac Attachment



SkimDoctor.com

By: Totally New Technologies LLC, Goodlettsville TN
SkimDoctor is Covered by U.S. Patent No(s). 8,721,881, US 8,864,986 & other U.S. & International Patents Pending.